



Insert the supplied shims when used on gates with less than a 17/8" tube.



Adjust Gate Wheel onto the bottom bar of gate. Insert bolts, secure with nuts.



Gate will roll open and close with ease.

